

# Hellwig PRODUCTS.com

559-734-7451 800-367-5480 TechSupport@HellwigProducts.com

## INSTALLATION INSTRUCTIONS

### 2500# Air Bag 2" Spacers

Thank you for purchasing a quality Hellwig Product.

PLEASE READ THIS INSTRUCTION SHEET COMPLETELY BEFORE STARTING YOUR INSTALLATION

**SAFETY: BEFORE STARTING YOUR INSTALLATION, BE SURE TO SET PARKING BRAKE AND CHOCK TIRES.**

**NOTE: THIS AIR BAG SPACER ONLY WORKS WITH HELLWIG 2500LB AIR BAGS, IT WILL NOT WORK WITH HELLWIG 2600LB AND 2800LB AIR BAGS**

**NOTE: YOUR LOWER PLATES MAY NOT EXACTLY MATCH THE ONES SHOWN IN THE PHOTOS**

**NOTE: YOU WILL HAVE EXTRA HARDWARE AT THE END OF THE INSTALL**



1. Apply the red loctite to the threaded stud and thread it into one side of the air bag spacer.
2. Thread the air bag onto the threaded stud from Step 1.
3. Run the bolt up through the lower bracket from your Hellwig air suspension kit and thread it into the other side of the air bag spacer. If your lower bracket has a through hole, use the standard bolt and washer, if it has a countersunk hole, use the flat head bolt.
4. Torque this bolt to 25 ft-lbs.
5. Continue install according to the Hellwig Instructions included in the air suspension kit.

**ATTENTION INSTALLER: BE SURE THAT THE CUSTOMER RECEIVES THIS INSTRUCTION SHEET, ALL IMPORTANT NOTE CARDS AND THE WARRANTY FORM**

#### **Maintenance and Inspection:**

Your Hellwig Suspension Product is built to last. However, as with all vehicle systems, it requires routine inspection. Inspect your Hellwig installation looking for secure hardware and tight fitting brackets and bushings. If you do not perform this inspection, have your professional mechanic inspect as described.